



OXVA

XLim Pro



User Manual

STRUCTURE



SPECIFICATION

Size	111×25×14.3mm
Cartridge capacity	2ml
Screen	0.42 inch OLED
Output Voltage	3.2-4.2V
Battery Type	Built-in 1000mAh
Charging	Type-C 5V/2A

GUIDANCE

1. FILLING JUICE

Fill the e-juice into the cartridge.



TIPS

- 1) After filling the e-juice into a new cartridge, please wait for at least 5-8 minutes before vaping to avoid dry burning.
- 2) After filling the juice, please close as soon as possible to avoid leaking.

2. POWER ON/OFF

Press the fire button 5 times in 2s to turn it on/off.

3. VAPING

While the device is on, press the fire button or draw to vape. The device will stop working when the vaping is longer than 8s due to safety protection.

4. ADJUST OUTPUT

Press the fire button 3 times in 2s to adjust your prefer wattage.

5. LOCK/UNLOCK

Press the fire button 4 times in 2s to lock/unlock the fire button.

6. LIGHTING ADJUSTMENT

Press the fire button twice in 1 second to adjust the lighting effect.

7. RESET PUFFS

Press the fire button 7 times in 2.5 seconds to reset the puff count.


LIGHT PROMPT

Vape over 8s	Blue light flashes 3 times and stop working.
High Temp	Red light flashes 5 times and stop working.
Low Battery	Red light flashes 10 times.
Short Circuit	Red light flashes 3 times.

STATEMENT

1. Please keep away from inflammable and explosive materials to avoid injury.
2. Please don't leave the device unattended while charging.

LA STRUCTURE DU PRODUIT



SPÉCIFICATIONS DU PRODUIT

Taille	111×25×14.3mm
Capacité du pod	2ml
Écran	OLED de 0,42 pouce
Tension de sortie	3.2-4.2V
Capacité de la batterie	1000mAh
Charger	Type-C 5V/2A

GUIDE D'OPÉRATION

1. REMPLIR LE JUS ÉLECTRONIQUE

Remplissez le jus électronique dans la cartouche.



ASTUCES

- 1) Après avoir rempli le jus électronique dans une nouvelle cartouche, veuillez attendre au moins 5-8 minutes avant de vapoter pour éviter de brûler à sec.
- 2) Après avoir rempli le jus, veuillez fermer le bouchon en silicone dès que possible pour éviter les fuites.

2. ALLUMEZ

Appuyez sur le bouton "fire" 5 fois en 2s pour l'allumer.

3. VAPING

Lorsque l'appareil est allumé, appuyez sur le bouton d'allumage pour fumer. Il sera forcé d'arrêter de fonctionner si le vapotage dure plus de 8 secondes en raison d'une protection de sécurité.

4. AJUSTEZ LA SORTIE

Appuyez sur le bouton de tir 3 fois en 2 secondes pour régler votre puissance préférée.

5. VERROUILLER/DÉVERROUILLER

Appuyez sur le bouton de tir 4 fois en 2 secondes pour verrouiller/déverrouiller le bouton de tir.

6. RÉGLAGE DE L'ÉCLAIRAGE

Appuyez deux fois sur le bouton d'allumage en 1 seconde pour régler l'effet d'éclairage.

7. RÉINITIALISATION DU COMPTE

Appuyez 7 fois sur le bouton de tir en 2,5 secondes pour réinitialiser le compte.

INVITE LUMINEUSE

Vape sur 8s Bleu rouge clignotent 3 fois et s'arrêtent de fonctionner.

Haute température voyant rouge clignotent 5 fois et cessent de fonctionner.

Batterie faible voyant rouge clignote 10 fois.

Court-circuit Voyant rouge clignotent 3 fois.

DÉCLARATION

1. Tenir loin des produits inflammables ou matériaux explosifs pour éviter toutes blessures .
2. Veuillez ne pas laisser l'appareil sans surveillance pendant le chargement.

WARRANTY POLICY

Thank you for purchasing OXVA product. OXVA will provide repair or replacement to the original purchaser under warranty according to the following terms and conditions:

1. The warranty covers defects in materials or workmanship, under normal use, for a period of 90 days from the date of purchase. Warrantor provides repair or replacement for all the defective parts.
2. This warranty may be disqualified as a result of the following circumstances:
 - * The customer does not provide this warranty card and the original receipt of purchase.
 - * Merchandise failure or damage is caused by improper use or unauthorized adjustments.
 - * Merchandise failure or damage as a result of excessive force or impact and non- recommended operating conditions. (see user manual)
 - * Merchandise failure or damage caused by exposure to water or other conducting liquids.
 - * Merchandise failure or damage caused by use with non-OXVA brand components or recommended e-liquids.
3. This warranty does not cover personal or consumable parts such as coil heads, USB cable, mouthpiece.

For more information please visit our website at www.oxva.com
Or email us at support@oxva.com

PURCHASE INFORMATION

Product Model: _____

Date of Purchase (Based on the date from receipt of purchase):

Day: _____

Month: _____

Year: _____

Store Information:

Store Name: _____

Phone: _____

Store Address: _____

City: _____

Country: _____

Post Code: _____

Customer Information:

Customer Name: _____

Phone: _____

Customer Address:

City: _____

Country: _____

Post Code: _____